

# New version multimeter


## Added functions

1. Add the AUTO intelligent mode
2. Add a reminder of incorrect connections
3. added frequency of testing
4. Add zero Firewire test

1. AUTO Intelligent mode: In AUTO mode, the DC/AC voltage is automatically switched. Resistance, Continuity



2. Add pen misconnection prompt: When the current gear and the connected pen do not match, the buzzer and red text on the page alarm



Added: connection diagram



1. Add the frequency of testing



2. Add zero firewire test: After correctly connecting the pen, the pen contacts the firewire buzzer

